

## Maintenance Staufix FKA in a chamber

### Article information

Item no.: 80117S

GTIN:

Price group: 00

### Description

Maintenance of the automatic backwater valve Staufix FKA in a chamber

### Scope of services (all work is carried out according to the inspection card):

- Functional check
- Removing the locking cover and inspecting the cover seal
- Removing the flaps, inspecting the flap seal, cleaning the components
- Greasing the moving parts
- Assembling the system
- Leak test
- Sealing the emergency closure (both flaps shut)
- System must be handed over in a safe operational state
- The recorded values are documented in a maintenance report

### Chamber systems:

- In the case of service work on chamber systems, according to BGV C5 § 34, BGR 236, the clearance measurements of sewer gases, the use of fall protection and for safety reasons an additional safety attendant are required
- The safety attendant must be provided by the customer and must be present for the entire duration of the work

### Requirements on site:

- Contact person must be on site
- Access to the system and control unit
- A hose water connection must be provided nearby

### Note:

- Regular maintenance is a prerequisite for the warranty and insurance cover
-

**Not included are costs for:**

- Material expenses over 20 euros
- Any additional incidental expenses are charged based on the expenses incurred
- Difficult conditions, repair services, additional work
- Wasted journeys despite prior notice

Backwater valves must be serviced every six months by a specialist company in accordance with DIN 1986-3.

The price stated is for each maintenance operation.

From the commissioning to the execution of the service, a processing time of 10 working days should be expected.